

OPTIPARTS

MARINE EQUIPMENT



FLEXIBLE PVC BOOT

*Flexible PVC boot to mount under ratchet blocks.
Keeps your block from hitting the deck without snagging lines.*



WWW.OPTIPARTS.COM

Foto by: Matias Cappizzano

Installation step by step:

1. Make sure you have the necessary tools:
 - Hairdryer or warm water
 - 2x zip ties
2. Soften the boot with a hairdryer or soak the "boot" in warm water.
3. Take the two zip ties and loop them through each side of the "boot".
4. Pull the zip ties tight until the "boot" compresses.
5. Attach your block to the eyestay.
6. Cut the zip ties.
7. The shape of the "boot" returns to normal when the boot cools down.



WARNING:

- Do not burn the "boot".

