Raymarine

T005 Strap Bracket

Installation instructions

Package contents: Strap Bracket, double sided Velcro strap, adhesive Velcro patch, two foam strips, nut, bolt, 2 washers.

- Stick the adhesive Velcro patch horizontally to the front of your mast at the intended height for the bracket
- Fit the cradle (supplied with your Micro Compass) to the bracket using the M4 nuts and bolts supplied
- Fit the foam pads to the bracket, to provide a cushion where the bracket will be in contact with your mast
- Attach one end of the Velcro strap to the patch at the front of the mast
- Offer the bracket up to the rear of the mast, and thread the Velcro Strap through the slots in the side of the bracket.
- Pull tight, and fasten
- Cut off excess Velcro, but leave AT LEAST 8mm (3") overlap
- Test for rotational stability. If you require more stability, then:
 - 1. Check the position of the foam pads, moving outwards if needed
 - 2. Tighten the strap hard, applying plenty of tension
 - 3. An option is to fit the bolt into the centre hole to prevent rotation
 - 4. Alternatively, buy a Raymarine slug (T932) & fit into the mast track

WARNINGS

- Compass is accurate only when mounted within 20° of the vertical. Do not lean compass to port or starboard.
- Do not mount within 2' or 0.6 m of magnetic objects. Note that a conventional compass is a magnetic object.
- !! Check your installation before you sail !! Raymarine does not carry responsibility for units lost at sea due to insecure fixing.

For further details contact your dealer or www.raymarine.com

UU009-rev5 Strap Bracket user guide